

INSTALLATION GUIDE


TRITON WATERPROOF BACKER BOARD

1. ENSURE FRAMING IS STRUCTURALLY SOUND AND PROPERLY ALIGNED

- Wall must comply with local building code and ANSI A108.11
- Use a minimum of 2"x4" wood studs or 20-gauge metal studs at maximum 16" o.c.

2. DETERMINE LAYOUT

- TRITON® Waterproof Backer Board edges parallel to framing must be structurally supported
- Cut TRITON Waterproof Backer Board to size, make needed cutouts and holes



3. ATTACH TRITON WATERPROOF BACKER BOARD TO FRAMING MEMBERS

- Use proper nails or screws at maximum 8" o.c.
- Keep fasteners 3/8" from edges & 2" from corners
- Attach backer to structural members, maintaining 1/8" gap between sheets (to be filled with mortar), and 1/4" gap between backer and floor/tub/shower pan (to be caulked appropriately) → Set fasteners flush with TRITON Waterproof Backer Board .

4. TREAT FASTENER PENETRATIONS

- Suggested method: Adhere Triton Seam Tape with mortar centered over penetrations, ensuring a minimum of 2" radius from penetration.
- Alternate Method: cover each penetration with Triton Adhesive Sealant

5. TREAT SEAMS AND PLUMBING PENETRATIONS

- Apply mortar to seams and embed waterproof tape
- Use of all appropriate Triton Watertight System accessories is required - Seam Tape, Inside Corners, Outside Corners, Pipe Collars, Mixing Valve Flanges, Niches, Benches, and Curbs. Only Triton Watertight System accessories may be used.

